

# **Customer Connections Portal User Guide**

- Request Bus Code, Facility Code
- Submit PDUP

Date: December 6, 2022

Version: 1.0

Classification: Public

Version 1.0 Page 1 Public



# **Table of contents**

About T	his Guide3
1.	Request Bus or Facility code from AESO
1.1.	Initiate Code Request
1.2.	Submit Code Request8
1.3.	Close Code Request9
1.4.	Remove Code Request
2.	PDUP submission to AESO
2.1.	Initiate PDUP data creation
2.2.	Submit PDUP data for review
2.3.	Accept PDUP data submission
2.4.	Re-open PDUP for correction
2.5.	Close PDUP data submission
3.	Clone PDUP data forms
4.	Download PDUP data
5.	Notifications to external user
5.1.	Email Notification Sample
6.	Appendix
6.1.	Abbreviations
6.2.	AESO Contact
6.3.	Portal Sign-Up or Sign-In Portal URL
6.4.	Email Notifications
7.	Revision History



## **About This Guide**

The 'AESO Enterprise Data Portal' is a suite of online portals meant to provide a unified platform for secure information exchange with external stakeholders. The 'Customer Connections Portal' is part of that suite, meant for exchange of data related to the Connection, Behind-the-Fence, and Contract processes. The Project Data Update Package (PDUP) submission process is one of the processes that have been built in the portal. The Transmission Facility Owners (TFO) and market participants (MPs) will use this portal at different stages of a project to submit PDUPs to the AESO.

This guide is specific to the functions performed by users to make a successful PDUP submission. The document will provide guidance on:

- How to request a Bus or Facility code from AESO
- How to perform PDUP submissions in the portal
- Notifications while performing the above functions

<u>Note</u>: In this document, the Customer Connections Portal will be referred to as CGA Portal or only Portal. Customer Connections Portal and CGA Portal are the same.


PDUP Submitter and External user terms are used interchangeably, which means the non-AESO portal user who are responsible for submitting the PDUP.

Screenshots have been created using dummy data and users and usernames have been stricken-off for privacy reasons.




# 1. Request Bus or Facility code from AESO

The externals users (TFO, study consultant etc.) that are responsible for PDUP submissions can request for Bus and Facility (Substation or Transmission Line) code via portal prior to their PDUP submission. The notification of request goes to the Project Engineer (PDUP Analyst) within AESO, who then provides the required code.




## 1.1. Initiate Code Request

1. Click on AESO Apps to see the project you are working on.






2. Open the project where you need to request the code.




3. Open the required stage of the project.




Open the required code request form
 Bus Code Request / Facility (Transmission Line) / Facility (Substation)





#### 1.1.1. Bus Code Request

1. Open a New 'Bus Code Request'



2. An empty Bus code request record will get created







- 3. The record can be filled in using either the List view or the Form view within the portal:
  - a. **List view**, with one click under the column name. 'AIES Topological Nodes' to be value will be provided by the AESO, so leave it blank. Fill rest of the fields and save



b. Form view, click on arrow or double click on the record to open the record in form view.






### 1.1.2. Facility Code Request

Facility code request (FCR) can be submitted for Transmission Lines or Substations. The process of opening the form, filling, submitting etc. will remain the same as the Bus Code Request except the 'Facility Code' field value will be provided by the AESO.




# 1.2. Submit Code Request

1. After the request fields are populated submit the request to the AESO by moving the stage from 'Initiate' to 'Submitted to AESO'



2. Confirm the request submission.




3. Multiple requests can be submitted from list view by selecting the records for submission and then using the SUBMIT button.





#### 1.3. Close Code Request


 The AESO project engineers will get notified when a request is submitted, and they will provide the 'AIES Topological Nodes' or 'Facility Code' value to fulfill the request and move it to 'Close' stage.



2. When closed, the system will generate a notification to the external user, so they can login to the portal to look up the code.

Examples of email notifications when AESO provides codes:

#### **Bus Code:**



#### **Facility Code for Transmission Lines:**






### **Facility Code for Substations:**




#### 1.4. Remove Code Request

A code request can be removed before it is submitted to AESO. To do that,

1. Select the record to be removed and click 'Deactivate'.



2. Confirm the deactivation, which will remove the request.




# 2. PDUP submission to AESO

An external user (TFOs, study consultant etc.) is responsible to create the data for PDUP submission in a stage of a project. Each PDUP goes through a business process flow:

#### Initiate > In Review > Accept > Close

Based on the stage of the project, the PDUP submission may or may not require data forms submissions.

PDUP submission types	Stage 1	Stage 2	Stage 3	Stage 4	Stage 5
PDUP Submission only with attached docs	Yes	Yes	Yes	Yes	Yes
PDUP Submission with data forms	No	No	Yes	Yes	Yes




### 2.1. Initiate PDUP data creation


#### 2.1.1. General Tab

- 1. Open the project and then open the stage where PDUP needs to be submitted. The external user must take care that they create PDUP in the required stage as the system does not restrict any stage from PDUP creation.
- 2. Click '+New CGA PDUP Submission' that will open a new PDUP form





3. Fill the fields under 'General' tab of the form and 'Save'. The PDUP business process flow will show in its INITIATE stage.





Field name	Mandatory	Description
Energization #	Yes	The serial number of the energization in the project. It must be unique value (1-99) within a stage.
Author Comments	No	Optional field, only for external user to enter their comments pertaining to the PDUP.
AESO Comments	No	Optional field, only for the AESO reviewers to enter their review comments.
Acceptance Comments	No	Optional field, only for the AESO reviewers to enter their review comments.

#### 2.1.2. Upload document to the PDUP data

Users can upload any supporting documents to the PDUP. They must use this function to submit the APEGA member attested copy of the coversheet with their PDUP. User should sign, stamp, scan & then upload the document to the PDUP before submitting it to the AESO.

To upload, go to 'Document' tab and upload documents as needed.



#### 2.1.3. PDUP data forms

PDUP data forms are required in stage 3, 4 and/or 5, depending on the project type.

- External users need to enter the list of Facility Equipment first which guides the generation of other
  dependent forms within PDUP as separate tabs. E.g., if a 'Generator' is entered in the equipment
  list, then these forms (tabs) will get generated in the PDUP Generator Control (mandatory),
  Energy Source (mandatory), Dynamic Simulation Model (mandatory), Control System (optional).
- The user will need to populate further details in those dependent forms before making the submission.
- The mandatory dependent forms will have records created automatically for the equipment mentioned in the Facility Equipment list. User will not be able to add any new record there for an equipment that is not mentioned in the Facility Equipment list.
- The optional dependent forms will be empty. If needed, the external user will create records for the
  equipment in those forms. The user will be able to add or delete records in the form before
  submission to AESO.
- The mandatory fields and forms should be completed before making the submission.


The table below describes the forms that will get created based on the equipment entered in the Facility Equipment form.



Equipment	Equipment type	Control System Type	Mandatory forms	# of forms per equipment per control system type	Optional forms	# of forms per equipment per control system type
	Generator DER	Generator	Generator Control Dynamic Sim Model Energy Source	1 1 1	Control system form	1 1
		Exciter	Energy source		Dynamic Sim Model Control system	1 1
		Governor			Dynamic Sim Model Control system	1 1
		Stabalizer			Dynamic Sim Model Control system	1 1
Generator		Generator Control			Dynamic Sim Model Control system	1 1
		Electrical Control			Dynamic Sim Model Control system	1 1
		Plant Control			Dynamic Sim Model Control system	1 1
		UVLS			Dynamic Sim Model Control system	1 1
		UFLS			Dynamic Sim Model Control system	1 1
		Other			Dynamic Sim Model Control system	1 1
Compensator	Series Compensator (static) Shunt Compensator (static) Reactor	Other	Compensator	1	,,,,,,	
Compensator	SVC (Static Var Compensator)	Other	Compensator Dynamic Sim Model (only for SVC)	1 1		
Transformer	Auto 2-winding 3-winding		Transformer Auto 2-winding 3-winding	2 (A,A) 2 (P, S) 3 (P,S,T)		
Load	Static	n/a	Energy Consumers Elements to MP	1 1		
Load	Motor	Motor	Control system form Energy Consumers Elements to MP	1	Dynamic Sim Model	1
AC Line Segment	AC Line Segment		AC line segment Branches	1 1		
For all equip					Mutual Coupling Topological Nodes	any # any #


# 2.1.4. Enter data in Facility Equipment form

1. Click Facility Equipment tab.







2. Click '+New Facility Equipment' to enter the facility details.



3. Save the Facility details by 'Save' or 'Save & Close' button.




4. The Facility code once entered cannot be changed, hence confirm the facility details are correct.





5. After saving the facility details, sub-grid will appear below to add equipment list. Click 'New Equipment'. An empty equipment record will get created to allow for equipment details.




- 6. The record can be filled in using either the list view or the form view:
  - a. List view, by one click under the column name. Fill rest of the fields and save.
  - c. Form view, click on arrow or double click on the record to open the record in form view.



- 7. Based on the equipment in the list, the mandatory dependent forms records will be created automatically. You will not be able to add any new record there for an equipment that is not mentioned in the Facility Equipment list.
- 8. The optional dependent form tabs will also get created but the records will be empty. If needed, create records for the equipment in those forms. You will be able to add or delete records in the form before submission to AESO. The optional forms are:
  - a. Topological Nodes form
  - b. Mutual Coupling form
- 9. Fill the forms that got generated Mandatory as well as optional, if required




#### 2.1.5. Fill out mandatory and optional dependent forms



#### 2.2. Submit PDUP data for review

1. After the all the required forms are filled, submit the request to AESO by moving the stage from 'Initiate' to 'In-Review'



- 2. Confirm the PDUP submission as the user cannot make any changes to the PDUP data after it moves to 'In-REVIEW' stage.
- 3. The submission will generate email notification for the AESO reviewers who will review the submission.

#### 2.3. Accept PDUP data submission

If the data submission meets the PDUP requirements, then the AESO reviewer will move the PDUP stage forward to 'ACCEPT'.



## 2.4. Re-open PDUP for correction

In case of deficiencies are found, then the reviewer will contact the external user via communication channel or other means and if needed, can choose to move the PDUP stage back to 'INITIATE' i.e., reopen the case for the external user to make corrections.

**Note**: Please refer to 'User Guide for Communication Channel' on how to use it.

#### 2.5. Close PDUP data submission


After PDUP submission is accepted by AESO then reviewer will move it forward to 'Close'. Once closed, no changes can be made to that PDUP submission.



# 3. Clone PDUP data forms


External users (PDUP submitter) can clone (or copy) PDUP data forms from previous stages to latter stages. It's helpful when the PDUP data for an equipment hasn't changed much from the previous stage and can be used in latter stages too with minimal updates by the external user.

- A PDUP can be cloned from,
  - Stage 3 to stage 4/ stage 5
  - Stage 4 to stage 5
- Multiple PDUP submissions of previous stages can be copied into one PDUP of latter stage.
- A PDUP can only be cloned once, it cannot be copied into multiple PDUPs within a stage.
- The PDUP energization no. of the destination PDUP can be different than the source PDUP.




To clone a PDUP from one stage to another:

- 1. Create a new PDUP where the data forms will be copied over from previous stage. Follow the same steps as mentioned in section 2.1.1.
- 2. After PDUP is created, click the 'Clone' button on top of the PDUP page.






3. List of PDUPs from previous stages will appear as options. Select the PDUP (one or more) to be copied and SUBMIT.




4. Confirm your cloning request





5. Cloning process may take some time to complete. User can view the cloning status by clicking 'Clone Request' Tab in the PDUP



- 6. The data forms will get added to the PDUP after the cloning job is complete (Status = Complete).
- 7. User shall then make changes to the forms as required before making submissions.


Note: Clone function can only copy the data forms, not the attachments to the PDUP.



# 4. Download PDUP data


Any Customer Connections portal user can download a PDUP package from the portal.

- The download can be done at any stage of the PDUP business process flow.
- The downloaded PDUP package will contain all the forms and document attachments that are visible to the user and are part of the PDUP package at the time of download.
- The PDUP package always gets downloaded to the 'Downloads' folder of the user. Users can move the folder after the download is complete.
- All the PDUP forms are downloaded into separate PDF documents. Any attachment to the PDUP is downloaded in their native file format.




#### To download a PDUP

1. Open the required PDUP that needs to be downloaded.






2. Click 'Create ZIP' button on top of the PDUP page.




3. Confirm your PDUP download request





4. Download process may take some time to complete. User can view the download status by clicking 'Zip Files' Tab in the PDUP



5. Once the download process is successfully completed, a notification is sent; only to the person who initiated the download. They can then login to the portal to fetch the zip folder.





6. If the download process fails, a notification is sent; only to the person who initiated the download.



# 5. Notifications to external user

Email notifications are generated for the portal users based on certain triggers within the Customer Connection processes. The notifications are either sent to the whole team or an individual user. Here are the triggers that initiate notifications for External Users when working with the Customer Connections Portal for PDUP submission.

Triggers	Notification to
Bus or Facility code request is completed by AESO	External User's Team
PDUP reopened by AESO for corrections by external user	External User's Team
When the download initiated by a user is complete	Only the user who initiated the download
Communication sent by any AESO user to the external user	External User's Team

## 5.1. Email Notification Sample

#### 5.1.1. PDUP Re-opened

PDUP Reopened - PDUP-3001-Stage 3-E1-01 CRM:0212424 Inbox x

SVC-Azure\_AesoIntegPortal\_Notify <svc-azure\_aesointegportal\_notify@aeso.ca>

o me

The AESO has reopened the PDUP-3001-Stage 3-E1-01 for corrections. Please login to CGA portal for further action.

Note: This is a system generated email. Please do not reply.

# 6. Appendix

#### 6.1. Abbreviations

- AESO Alberta Electric System Operator
- CGA Customer Grid Access
- PDUP Project Data Update Package
- PM Project Manager

#### 6.2. AESO Contact

Users can contact <u>customer.connections@aeso.ca</u> for any questions about this user guide, or support needed in using the portal.

# 6.3. Portal Sign-Up or Sign-In Portal URL

• <a href="https://aeso-portal.powerappsportals.com/">https://aeso-portal.powerappsportals.com/</a>

#### 6.4. Email Notifications

To receive timely notifications, the portal users shall take care that the emails from following senders are not marked as spam.

• svc-azure aesoportal notify@aeso.ca.

# 7. Revision History

Revision	Date	Comments
1.0	Dec 06, 2022	Initial version