
INT-001-AB-3 Interchange Information

1. Purpose

The purpose of this *reliability standard* is to require that *interchange* information is submitted to the *interchange authority*.

2. Applicability

This *reliability standard* applies to:

- *ISO*

3. Definitions

Italicized terms used in this *reliability standard* have the same meanings as set out in the [Alberta Reliability Standards Glossary of Terms](#) and Part 1 of the [ISO Rules](#).

4. Requirements

R1 The *ISO* must submit to the *interchange authority*, for an *interchange transaction* that sinks in Alberta, the *arranged interchange* in each of the following circumstances:

R1.1 If a *pool participant* is not involved in the *interchange transaction*.

R1.2 If the *interchange transaction* is a bilateral *inadvertent interchange* payback.

5. Processes and Procedures

No procedures have been defined for this *reliability standard*.

6. Measures

The following measures correspond to the requirements identified in Section 4 of this *reliability standard*. For example, MR1.1 is the measure for R1.1.

MR1 Measures for this requirement are identified in the subsections below.

MR1.1 *E-tags*, voice recordings, or other documentations exist and are provided upon request, and can be used to confirm that an *arranged interchange* was submitted to the *interchange authority*.

MR1.2 *E-tags*, voice recordings, or other documentations exist and are provided upon request, and can be used to confirm that an *arranged interchange* was submitted to the *interchange authority*.

7. Appendices

No appendices have been defined for this *reliability standard*.

8. Guidelines

No guidelines have been defined for this *reliability standard*.

Revision History

Effective	Description
2009-10-03	New Issue